



RANGE DIMENSIONS  
OR24SDMBGX, OR24SDPWGX, OR24SDPWSX




DIMENSIONS INCHES (MM)

	OR24SDMBGX	OR24SDPWGX	OR24SDPWSX
A Overall width	23 7/8" (606.5)	23 7/8" (606.5)	23 7/8" (606.5)
B Overall depth (without handle)	24 5/16" (611.6)	24 1 1/4" (614.1)	24 1 1/4" (614.1)
C Height (without backguard)	Min 35 1/16" (900) Max 36 7/32" (920)	Min 35 1 1/32" (902.5) Max 36 7/32" (920)	Min 35 1 1/32" (902.5) Max 36 7/32" (920)
D Backguard	5" (127)	5" (127)	5" (127)

Product dimensions and specifications are listed as a guide only. For complete installation instructions and specifications, refer to the product Use & Care Guide/Installation Instructions available at [www.fisherpaykel.com](http://www.fisherpaykel.com)

**FREESTANDING RANGE PROXIMITY TO SIDE CABINETS**  
**OR24SDMBGX, OR24SDPWGX, OR24SDPWSX1**



**DIMENSIONS INCHES (MM)**

	OR24SDMBGX	OR24SDPWGX	OR24SDPWSX
A To nearest soft furnishing/combustible surface	20" (500)	20" (500)	20" (500)
B Max bench height	36" (914)	36" (914)	36" (914)
C Min height of cabinet above range	30" (762)	30" (762)	30" (762)
D Side cabinets minimum height above	18" (457)	18" (457)	18" (457)
E Min. nearest combustible surface (joinery) if side is above 36" min. distance to RH wall min. distance to LH wall due to burner sizes.	11 <sup>13</sup> / <sub>16</sub> " (300) 3 (76)	11 <sup>13</sup> / <sub>16</sub> " (300) 3 (76)	3" (76) 3" (76)
F Max. cabinet depth (above range)	13" (330)	13" (330)	13" (330)

Product dimensions and specifications are listed as a guide only. For complete installation instructions and specifications, refer to the product Use & Care Guide/Installation Instructions available at [www.fisherpaykel.com](http://www.fisherpaykel.com)